



The kit will include hardware with 6 spacers. Three for each side. The car will have 3 pre-existing holes. Insert the 3 bolts into the nerf bar holes. Place the 3 spacers on each of the bolts. Set the nerf bar in place making sure the spacers stay in place as well as the top mounting spacers.

Remove the existing side plates and retain the top mounting spacers.

Note: it will work best if you leave all the mounting bolts loose until all hardware is in place and than tighten completely.



