

# Sport Windshield

## Yamaha G14/G16/G19/G22

### WND YA3 1002



**BUGGIES**  
UNLIMITED

Hardware Kit Includes:

- (2) 1 1/2" X 5/16" X 18 Bolts
- (4) Flat Washers
- (2) 5/16" Locknuts
- (2) Windshield Support Studs
- (2) Spacers
- (2) 10mm Nuts



**CAUTION:** Remember to wear appropriate eye protection while performing the tasks in this instruction.

Installation Instructions:

1. Remove top from golf cart using 13mm ratchet and wrench. Save factory hardware for later use.
2. Remove sport windshield from box and align windshield so that it rests on the two posts on the front cowl. (See Figure 1) Most Yamaha G14/G16/G19/G22 models will have two existing posts on the front cowl where the roof struts connects to the front cowl of the body. For carts that don't, please align windshield and mark holes on front cowl. Use drill bit to drill marked holes, and then install (2) included windshield support studs. NOTE: If using the (2) included windshield support studs, use the 8mm (small end) threaded side down on G14/G16/G19 models, and use the 10mm (large end) threaded side down on G22 models. If using windshield support studs on a G22, the (2) included spacers will have to be used on as shown in Figure 2. This will assure a uniform fit for the windshield.
3. Once windshield is on front cowl posts, the rear brackets should sit on the black rubber molding strip on top of the dash. (See Figure 3) Mark drill holes with marker or pen. (See Figure 4)
4. Use a 5/16" drill bit to drill the marked holes for the back mounting brackets. (See Figure 5) NOTE: A box cutter or knife may be used to notch out the black rubber molding strip before drilling
5. Align rear mounting brackets with drilled holes and mount to cart using supplied 5/16" bolts, washers, and nuts. Tighten hardware.
6. Attach factory hardware to front posts. Tighten all hardware at this time.
7. Remove protective film from windshield.



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5