

**Yamaha Drive G29 Brush Guard  
Installation Instructions**  
Black- Part# 6297  
Gunmetal- Part# 7073  
Stainless- Part# 6296



Parts List

Brush Guard-1



*Always wear appropriate  
eye protection!*

1. Slide the rubber protective roof support grommets up the roof supports as shown in Figure 1.
  2. Remove the stock bolts from the roof struts and the front bottom cowl bolt. Save these bolts for installation of Jake's brush guard.
  3. Slide brush guard into place. Using the stock bottom cowl bolt, loosely mount the bottom brush guard tab to the cowl and frame.
  4. Using the stock roof strut bolts, mount the brush guard to the struts and the cart as shown in Figure 2.
- NOTE: Start bolts on both sides before tightening!**
5. Securely tighten all bolts.
  6. Reinstall the stock rubber roof support grommets.



866-405-2537

[www.jakesliftkits.com](http://www.jakesliftkits.com)