

WND YA4 WBC
WND YA4 WBT
Clear or Tinted Windblocker
Yamaha G22 (GMAX)



INSTALLATION INSTRUCTIONS

1. Windshield must be folded down to install
 2. Place windblocker on top flange below roof.
 3. Slide windblocker up as far as possible on roof struts.
 4. Use holes on windblocker to mark top flange.
 5. Drill marked holes with 1/4" drill bit.
 6. Place plastic bolts through windblocker.
 7. Place rubber washer between windblocker and top flange.
 8. Place nut on back side of top flange. Gently tighten.
- * Windblocker will not work with winged windshields.

BW 307

Buggies Unlimited
1-888-444-9994
www.buggiesunlimited.com
Copyright©1997-2008 Buggies Unlimited.
All Rights Reserved.

WND YA4 WBC
WND YA4 WBT
Clear or Tinted Windblocker
Yamaha G22 (GMAX)



INSTALLATION INSTRUCTIONS

1. Windshield must be folded down to install
 2. Place windblocker on top flange below roof.
 3. Slide windblocker up as far as possible on roof struts.
 4. Use holes on windblocker to mark top flange.
 5. Drill marked holes with 1/4" drill bit.
 6. Place plastic bolts through windblocker.
 7. Place rubber washer between windblocker and top flange.
 8. Place nut on back side of top flange. Gently tighten.
- * Windblocker will not work with winged windshields.

BW 307

Buggies Unlimited
1-888-444-9994
www.buggiesunlimited.com
Copyright©1997-2008 Buggies Unlimited.
All Rights Reserved.