

CLR UNV GC1F FENDER MOUNT COOLER KIT Installation Instructions

Locate the cooler bracket and cooler on the rear fender so that the bag rack and golf bag will not interfere with the removal of the cooler.

Hold the bracket in position and mark the four mounting bolt holes. Drill the four holes with a 1/4" drill bit. Install the bolts and nuts by reaching under the rear body and fender area. The four rubber spacers (included) are used on some carts to level the cooler.

On some carts, such as Yamaha G16 models, you can cut a hole in the underside fender well to install the bolts and nuts. A Dremel or similar cutting tool or a hole saw works well for that.

