

# Xtreme Mats Golf Cart Floor Mat Instructions with Clips

Xtreme Mats Golf Cart Floor Mats covers your entire OEM flooring from the bottom of the dash down to the base of the seat. These floor mats are perfect for your golf cart; they keep dust, dirt, sand, and moisture out, so you don't have to worry about ruining your beautiful golf car.

## Installation on the following models: Yamaha / ICON / Advanced EV1

The Xtreme Clips work by securing the Xtreme Mat to the OEM (manufacturing) flooring under the dash. The long arm of the clip goes underneath the factory flooring, and the small arm hooks over the trim edge of the Xtreme Mat.

**Before installing the mat, be sure the golf cart is turned off.** Lay the mat in the cart by going around the foot pedals carefully and up under the dash. With the Xtreme Mat in place, look under the dash to find the edge of the factory flooring and pull the mat and the factory flooring slightly away from the cart's frame. Take the short arm of the clip with the slightly hooked edge and place that against the inside lip of the trim piece. With the long arm facing away from you toward the factory flooring and the short arm pressed against the lip of the trim, pull the manufacturer flooring together with the Xtreme Mat, swing the clip around, and slide it under the manufacturing flooring. Press the flooring back down into place once it has been secured to the Xtreme Mat. The two mats will now be clipped together, as in the illustration below. You will receive 4 clips with your purchase, and they can be placed anywhere under the dash where you are able to access the edge of the factory flooring to attach them.

*The picture below only shows how the clip attaches the Xtreme Mat to the factory flooring, not where it should be attached. The clips go anywhere along the top of the mat where it meets the dash, not on the sides of the cart.*

