

T-Bar Rear Seat Handle

Universal-Fits All BU Flip Flops

HDL FFBU BLK

CONTENTS:

- (1) T-Bar Handle
- (1) Base
- (4) 5/16" x 2" Bolts
- (4) Washers
- (4) Nuts

Tools Needed:

- Drill
- 5/16" Drill Bit
- 5/16" Ratchet
- 5/16" Wrench

Installation Instructions:

1. Place base in center of foot rest to use as template in order to mark holes for mounting, on top and front face of foot rest. (See Figure 1)
2. Drill marked holes in top and front of foot rest. (See Figure 2)
3. Place base onto foot rest with holes lining up. With a washer on both sides of base mounting holes insert (2) 5/16" x 2" bolts in top and (2) 5/16" bolts in front face holes. (See Figure 3)
4. Secure each bolt with a nut on back side of base.
5. Tighten all hardware with 5/16" ratchet and 5/16" open face wrench.
6. Insert handle into base. (See Figure 4)
7. Secure by inserting and tightening knob. (See Figure 5)

