

TPS ML 2495

Top Shelf Overhead Storage Tray

Tools Required:

Utility Knife

Tin Shears

5/16" Nut Driver or Socket

Safety Glasses



CAUTION: Remember to wear appropriate eye protection while performing the tasks in this instruction.

Installation Instructions

1. Measure your front frame where Top Shelf is to be placed. (Outside to outside of frame where it fits into top)
2. Trim Top Shelf to fit your measurements using a utility knife or tin shears. Some tops require more trimming than others. (Trim one side of Top Shelf to ensure proper fit)
3. Hold Top Shelf in place to ensure it has been trimmed properly. (If further trimming needs to be done, do it at this time.)
4. Using the self tapping screws and a 5/16" nut driver or socket, screw the Top Shelf in place at the bottom of front frame where frame fits into top.
5. Using a utility knife, trim any excess scrap to ensure a clean, professional look.

Depending on the golf cart and top used, easy modification allows quick installation. Below are examples of what may be encountered on various tops. Measure your own vehicle top before modifying to assure that there will be a correct fit.

