


36/48 Volt Heater

Sample Battery Pack
(six 8 volt batteries)

Black 12 Volt Negative Connection*












16 to 12 Volt
Reducer Sample



* For cars using six 8 volt batteries a voltage reducer must be used on the fan negative wire. For all other battery configurations use a single twelve volt battery or two 6 volt batteries in series from the first car positive connection. See battery chart for first Positive connection and battery numbers. The larger Black wire connects to battery 4,6 or 8 Negative connection to the car.



Always wear appropriate eye protection and if the car utilizes a run/tow switch place the switch in tow position before battery disconnect!



- A = DS 36 Volt Club Car
 B = G19 48 Volt Yamaha
 C = Precedent
 D = Drive
 E = DS 48 Volt Club Car
 F = Marathon
 G = RXV
 H = TXT
 I = Yamaha 36 Volt
 J = 12 Volt Gas Cars
 K = G22